

XR8 SERIES LINE UP

GE-0621 XR8-2 STANDARD VERSION

GE-0622 XR8-2 COMPACT VERSION 1

GE-0623 XR8-2 COMPACT VERSION 2

GE-0624 XR8-2 DMAR VERSION



星虹

STAR RAINBOW TOYS CO., LTD

<http://www.starrainbow.com.tw>

MADE IN TAIWAN

(SRC)
PRODUCED IN TAIWAN

XR8-2

NEW GENERATION ASSAULT RIFLE

次世代突擊步槍

INSTRUCTION MANUAL



警告
WARNING

18

限18歲以上使用
For age 18 and older



使用前請詳細閱讀說明書
Read manual before use

注意事項

警告 本玩具為無法改造成為有殺傷力之玩具槍，請勿嘗試改造以免損壞內部精密機構

警告 此玩具槍有可能讓警方或民眾誤以為真槍，導致危險或恐慌，請勿除去或修改槍上之標記。

警告 請勿在任何的公共場所把玩、展示、射擊，或任何導致一般民眾恐慌之行為上述行為有可能違反社會秩序維護法

警告 請勿對標靶以外之人體、動物、射擊，以免造成受傷或損害物品遭受刑責處分

PRODUCT ADVISORY

WARNING! Do not change, obscure, alter, remove, or obliterate any coloration or markings on this gun. The coloration and/or markings on this product, including the blaze orange barrel tip are designed to comply with applicable state and federal law and regulations.

WARNING! This product may be mistaken for a firearm by law enforcement officers or others. Any person who changes, alters, removes, or obliterate any coloration or markings that are required by state or federal law or regulation, in any way that makes this product look more like a firearm is guilty of a misdemeanor.

WARNING! The open display, brandishing and/or exposing of this product in any "public place" may cause confusion and may be a crime.

The term "public place" means any area opened to the public, including but not limited to, streets, sidewalks, bridges, alleys, plazas, parks, driveways, front yards, parking lots, automobiles, whether moving or not, and buildings opened to the general public including those that serve food or drink, or provide entertainment, and the doorways and entrances to buildings or dwellings.

WARNING! Every person who, except in self-defense, draws or exhibits this product in a threatening manner against another in such a way as to cause a reasonable person apprehension or fear of bodily harm is guilty of a misdemeanor punishable by imprisonment in the county jail for a term of not less than 30 days.

使用前請詳細閱讀說明書


Read user's manual before use!



無論是在一般射擊或是遊戲的時候
請全程佩帶護目鏡
When shooting at a target or playing a game,
you must wear goggles or any other eye protection.



射擊外請關上保險並請勿將手指伸入護弓內磁板機，避免誤擊
Never put your finger on the trigger unless you are ready to shoot. Always set the selector switch to the safe position when you are not firing the gun.




請在空曠的場地射擊或是遊戲，以免造成危險
Please select a safe place to play!



請遠離孩童可以觸及的地方
Please keep away from children!



彈匣卸下後槍管內可能還有子彈，無論有沒有子彈
絕對不要向槍口窺視
BB's might remain in the barrel after the magazine
has been removed! Do not look into the muzzle!
It is extremely dangerous!



請勿對人或動物射擊或將槍口朝向標靶以外
目標
Do not aim or fire at a human or animal.





請勿嘗試分解、改造、改裝槍枝
Disassembling or modifying the gun
may cause serious damage to your gun.




槍枝在不使用時或是攜帶途中，請放至於槍盒
或是槍袋中
Please put the gun in a case or a carrying bag
when transporting your airsoft gun.


槍枝結構 COMPONENT NAMES



電池安裝說明 HOW TO INSERT BATTERY



步驟一 將護木固定插銷卸下，並插入提把的孔內防止遺失
步驟二 將護木往下開啟
Step 1 Remove handguard lock pin, put it into the hole of carrying handle to prevent missing
Step 2 Open the lower handguard




將電池放入下護木，並接好接頭
Put the battery into lower handguard, and connect the connector




將護木蓋回，並插入護木固定插銷，並插入手槍固定插銷
Put lower handguard back, and insert handguard lock pin




彈匣操作 HOW TO LOAD THE MAGAZINE




將彈倉蓋向上掀開並倒入BB彈
Open the cover of magazine and insert BBs in to the magazine



依箭頭方向將發條上緊
Turn the gear at the bottom until heard click sound




彈匣不需彈匣連結器可輕鬆並聯
The magazines could connect together without magazine connector




使用SRC快速撥彈器更輕鬆有效率
Use SRC MR.ROLL UP could charge the magazine fast and easily



安裝彈匣 HOW TO USE THE MAGAZINE




將彈匣插入彈匣插口直到聽到喀一聲
Put the magazine into the magazine base until heard click sound



卸下彈匣時先按下彈匣卡榫，即可卸下彈匣
Press the magazine release button to remove the magazine


射擊選擇鈕操作 SELECTOR LEVER & SAFE



保險 SAFE





半自動 SEMI AUTO





全自動 FULL AUTO



伸縮槍托操作 HOW TO OPERATE RETRACTABLE STOCK




上旋器調整 HOP UP ADJUSTING




摺疊準星&照門操作 HOW TO OPERATE FOLDING FRONT & REAR SIGHT



準星調整 SIGHT ADJUSTING



狙擊鏡調整 SCOPE ADJUSTING



操作 Q&A TROUBLE SHOOTING

槍枝狀況 SYMPTOM	故障原因 CAUSE	排除方式 ACTION
不作動 No Operation At all	保險未開 Selector lever set to SAFE	將保險撥至連發或單發 Set the selector lever to AUTO or SEMI
	電池沒電 Battery is not charged	電池充電 Charge the battery
	電池接觸未接 Battery connector is disconnected	接合接頭 Connect the connector
	馬達機壽命已到(五萬發) Expired motor life (50,000)	更換馬達 Replace the motor
	保險絲燒毀 FUSE is blown out	更換保險絲 Replace the FUSE
馬達有動作 卻不能發射 Motor is revolving but gun doesn't work	齒輪故障 Faulty gear	請至專門店維修 Purchase the replacement gear from the dealer
	子彈卡在膛室 Bullets are clogged in the chamber	使用通條疏通子彈 Using the cleaning rod to remove the bullet
	子彈卡在彈匣 Bullets are clogged in the magazine	請翻拍彈匣 並確定使用SRC精密彈 Shake the magazine and confirm use SRC precision BBs
單發不正確 Malfunction of SEMI auto	齒輪正時未對準 Deviation in gear timing	切至連發射擊二-三秒再切至單發 Set to SEMI after firing 2-3 sec in Full AUTO
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發不正確 Malfunction of FULL auto	齒輪正時未對準 Deviation in gear timing	切至齒輪再切至連發 Set to SAFE first then set to Full auto again
	控制桿磨損 Faulty gear lever	請至專門店維修 Purchase the replacement parts from the dealer
連發速度變慢 Firing circle slow	電池即將沒電 Insufficient battery power	請充電並確認使用SRC專用電池 Charge the battery and make sure use SRC batteries
子彈飛行距離近 Shooting distance short	HOP UP沒作動 HOP UP system doesn't working	調整 HOP UP Adjust HOP UP
	Bb彈不良 Faulty BB bullets	請確定使用SRC精密彈 Please use SRC precision BBs
	O環磨損 Faulty O-ring	請至專門店維修 Purchase the replacement parts from the dealer
槍枝異音或其他 Loud or other	槍枝操作不正確 Operation doesn't correctly	請至專門店 Purchase the replacement parts from the dealer